

FITTING INSTRUCTIONS – CAPRI REAR SPOILER (TURBO)

- 1. If a spoiler is already attached to the car, remove the old spoiler and seal the holes with tape.**
- 2. Mark dimensioned holes according to the sketch and bore through outer and inner panel with a 9 mm drill, as shown detail.**

Bore or file holes in interior panel wider to a size of 18 mm dia.

Fit lower parts of the spoiler (A) to holes and align.

File holes wider if needed. Screw lower part of spoiler (A) in tightly. Mark both holes (G) – right and left – on the outer edges.

Remove lower part of spoiler (A) from car.

Drill indicated drill holes (G) to 4 mm.

- 3. Protect all drilled holes from rust. Wrap the bolts on lower part of spoiler (A) with sealant.**
- 4. Hold lower spoiler part (A) to holes, fit spoiler and fasten. Seal large holes 18 mm from inside with plugs. (Detail)**
- 5. Screw studs (B) left and right into lower spoiler part (A), with the long threaded part in the spoiler**

Fasten the side parts (C) and (D) with nuts and seal holes with plugs.

- 6. Mount brackets (F) onto the upper part of the spoiler (E) as shown.**

Now set the spoiler upper part (E) into the guides of the side parts (C) and (D) from the rear, and simultaneously push forward.

Fasten the middle fastening point with 2 screws.

Seal holes with plugs.